



MOUNTING INSTRUCTIONS FOR H. H. SCOTT COMPONENTS

"C" SIZE UNITS:

260B, 299F, 312D, 315, 342B, 382B, LT-112B-1, LK-60B

Case Mounting Hardware

Hardware for mounting the above units is supplied with the accessory cases. Wooden cases are supplied with hardware packet ZP-10. Metal cases are supplied with hardware packet ZP-13. See (1) and (2) below for mounting instructions.

Custom Mounting Hardware

All of the above units, require hardware packet ZP-17 for custom mounting. Custom mounting hardware may be ordered from our Parts Department. See (5) below for mounting instructions.

Case Mounting Hardware

Hardware for mounting the above units is supplied with the accessory cases. Wooden cases are supplied with hardware packet ZP-16. Metal cases are supplied with hardware packet ZP-12. See (3) and (4) below for mounting instructions.

Custom Mounting Hardware

The above units require hardware packet ZP-16 for custom mounting. Custom mounting hardware may be ordered from our Parts Department. See (6) below for mounting instructions.

"K" SIZE UNITS:

348, 388, 344-C, 384, LR-88, only available in wood.)

"C" SIZE (Wood and Metal)

(1) Remove the rubber feet if they are attached to the unit. Support the case on its rear edge between two books. The component is always inserted in the opening away from the grille. Slide the component down into the case holding the back of the component with your left hand and the front with your right. SEE FIGURE 1. When the set is $\frac{3}{4}$ in the case, lie the entire assembly down on its feet. Now slide the set the rest of the way in. Be very careful not to dislodge any tube while inserting the component. Stand the unit again on its rear edge and position the unit so that the four holes in the bottom line up with the four holes in the case. Should the holes not line up precisely, run one of the screws into the holes, without the foot attached, so that a thread is started.

(2) Install the longer, 1" sheet metal screws in the feet in place of the $\frac{5}{8}$ " screws. Start the screws into the holes (see note below). DO NOT TIGHTEN. Correctly position the unit in the case and install the rubber spacers between the unit and the case near the screws, where needed to hold the set in position. SEE FIGURE 2. Tighten the feet and screws so that they are snug. Do not overtighten.
NOTE: The metal cases use spacers with a hole in the middle. The spacers should be installed between the unit and the case before the screws are started into the holes in the set. SEE FIGURE 3.

"K" SIZE (Wood and Metal)

(3) WOODEN CASE: Using ZP-16 hardware, snap the plastic inserts into the square holes near each edge of the bottom cover. Follow the instructions in (1) above and install the spacers as in (2). Install the drive screws and washers through the case and into the inserts. SEE FIGURE 4 AND 5. Screw in snugly. Do not overtighten.

(4) METAL CASE: Use ZP-12 hardware and follow the instructions in (1) and (2).

CUSTOM MOUNTING

"C" SIZE UNITS

(5) Remove the rubber feet attached to the unit. Using ZP-17 hardware (see note below for 314 and LC-21) snap the plastic inserts into the square holes near each edge of the bottom cover. Place the set into position and install the drive screws and washers through the mounting shelf and into the inserts. SEE FIGURE 4. Screw in snugly. Do not overtighten.

"K" SIZE UNITS

(6) Use ZP-16 hardware and follow the procedure in (5) above.

H.H. SCOTT, INC.
111 Powdermill Road

For more information or replacement of misplaced hardware, contact: Maynard, Massachusetts
(D-3B)