


CONNECTION
 To connect the MB 40, it is first necessary to disconnect TAPE DECK ONE from the AMPLIFIER and route it through the MB 40 as shown. Two additional pairs of cables will be required to connect the MB 40 to the AMPLIFIER. All TAPE DECKS then connect directly to the MB 40.



OPERATION
 When using any of the TAPE DECKS either for recording or playback via the AMPLIFIER, just push the appropriate button T1, T2 or T3 respectively. For recording from one tape deck to another, just press the appropriately marked button. For example '1 > 2, 3' (tape 1 to tape 2 and/or tape 3) or

'2 > 1, 3' (tape 2 to tape 1 and/or tape 3) or '3 > 1, 2' (tape 3 to tape 1 and/or tape 2). A signal is automatically routed back to the amplifier for monitoring purposes. For recording from the AMPLIFIER on to either tape 1 and/or tape 2 and/or tape 3 just press 'A > 1, 2' or 'A > 2, 3' respectively.